



F5XT


User's Manual
Manual del usuario
Bedienungsanleitung

Manuel d'utilisation
Handleiding
Manuale dell'utente

Podręcznik użytkownika
Руководство пользователя
Manual de utilizador




사용 설명서
ユーザーズマニュアル
使用説明書

Instruction Guide




Cable Installation

F5XT Cable :



Dimension



Infomation

Thank you for purchasing a High-Quality Aerocool Product.
If you have any question while using our products, please feel free to contact us at:

www.aerocool.com.tw
sales@aerocool.com.tw

All rights reserved by Aerocool

Aerocool Advanced Technologies Corp. Taipei Headquarters 3F-6., No.79, Sec. 1, Xintai 5th Rd., Xizhi Dist., New Taipei City 221, Taiwan (R.O.C.)

Tel: +886 2 86981088 Fax: +886 2 86981082 www.aerocool.com.tw

100

95

75

25

5

0