




HOW TO ENSURE PWM HUB IS FUNCTIONING CORRECTLY ?

Connecting cables to the PWM Hub is easy. To ensure your fans are functioning correctly please see the figure below for the correct connector installation.



PWM hub layout in DS 230:

CN1: PWM Signal input

Must be connected to motherboard's PWM Connector. If not connected to motherboard, the LED will not function.

CN2: 4-pin PWM fan connector

Connect main PWM fan to set the PWM LED mode on.

CN3-CN4: 4-pin fan connector

CNA5-CNA8: 3-pin fan connector

Please note:

1. Refer to your motherboard's manual to ensure the fan connector is **in PWM mode**.
2. We recommend connecting the CHA_FAN connector to CN1.
3. Please refer to the image below to find the PWM connector on the motherboard.

