DS230 USER'S MANUAL

Illustration of Case

(For reference only. Models' option may be varied by countries.)

Top View

Rear View

Left View (Open)

Front View

Right View (Open)

1. PSU Location

2. Top I/O

3. 2.5" HDD /SSD

4. Motherboard

5. Front Panel

6. 2.5" HDD / SSD

7. 3.5" HDD

Accessory Bag Contents

Motherboard Standoff

Motherboard Screw
SSD Screw
ODD Screw

PSU Screw
PCI Screw

3.5" HDD Screw

Fan Screw

Cable Connection for Front I/O

RESET SW   POWER SW   HDD LED   HDD LED+ HDD LED-

HD AUDIO

USB

Fpanel Connector

(Please refer to your motherboard's manual to connect.)

Installation Guide

**Install Motherboard Stand-offs according to your Mb's form factor.**

**Install fan / radiator on top plate**

X4

**Install 3.5" HDD**

**Install 2.5" SSD**

Remove the front panel

Install fan / radiator on front plate

Install fan or radiator on top plate

PWM hub installation

1. DC 12V Power
2. PWM Signal - to M/B   *1
3. Main PWM Fan *2
4-5. 4 Pin Fan connector
6-9. 3 Pin Fan connector

1. Please refer to your motherboard's manual to make sure the PWM function is on.

2. Make sure to connect a PWM fan to turn on the PWM lighting effect

LED lighting effect

LED color switch
LED Mode switch

Color Switch :   Red - Green - Blue - Orange - Purple - Cyan - White - PWM Color (Blink twice)

PWM Color :

Green	0 - 20%	Fan Speed
Blue	20-40%	Fan Speed
White	40-60%	Fan Speed
Orange	60-80%	Fan Speed
Red	80-100%	Fan Speed

MODE :   On - Off - Breathe

Thank you for purchasing our High-quality Product.

If you have any question while using our products, please visit our website for latest driver & user manual .